



Tone List

GBN	PC	CC00	Sound Name	GBN	PC	CC00	Sound Name	GBN	PC	CC00	Sound Name	GBN	PC	CC00	Sound Name
A11	1	0	Piano 1	A32	18	0	Organ 2	A58	40	0	SynthBs2	B11	65	0	SoprSax
A111	1	8	Piano1w	A321	18	8	DetunOr2	A581	40	8	SyBass 4	B12	66	0	Alto Sax
A112	1	16	Piano1d	A322	18	32	Organ 5	A582	40	16	RubrBass	B13	67	0	TenorSax
A12	2	0	Piano 2	A33	19	0	Organ 3	A61	41	0	Violin	B14	68	0	BaritSax
A121	2	8	Piano2w	A34	20	0	Church1	A611	41	8	SViolin	B15	69	0	Oboe
A13	3	0	Piano 3	A341	20	8	Church2	A62	42	0	Viola	B16	70	0	EnglHorn
A131	3	8	Piano 3w	A342	20	16	Church3	A621	42	116	BrassOct	B17	71	0	Bassoon
A14	4	0	HonkTonk	A35	21	0	Reed Org	A63	43	0	Cello	B18	72	0	Clarinet
A141	4	8	HonkTnkw	A351	21	116	Or Orgn2	A64	44	0	Contrabs	B21	73	0	Piccolo
A15	5	0	E.Piano1	A36	22	0	AccordFr	A65	45	0	TremoStr	B22	74	0	Flute
A151	5	8	DetunEP1	A361	22	8	AccordIt	A66	46	0	Pizzicat	B23	75	0	Recorder
A152	5	16	EPiano1v	A37	23	0	Harmonic	A67	47	0	Harp	B24	76	0	PanFlute
A153	5	24	60'Piano	A38	24	0	Bandneon	A68	48	0	Timpani	B25	77	0	BotBlow
A16	6	0	E.Piano2	A41	25	0	NylonGtr	A71	49	0	Strings	B26	78	0	Shakuhac
A161	6	8	DetunEP2	A411	25	8	Ukulele	A711	49	8	Orchestr	B27	79	0	Whistle
A162	6	16	EPiano2v	A412	25	16	NylonGto	A72	50	0	SlowStr	B28	80	0	Ocarina
A17	7	0	Harpsi	A413	25	32	NylonGt2	A73	51	0	Syn Str1	B31	81	0	Square W
A171	7	8	CouplHps	A42	26	0	StStrGt	A731	51	8	SyStrng3	B311	81	1	Square
A172	7	16	Harpsi.w	A421	26	8	12-strGt	A74	52	0	Syn.Str2	B312	81	8	SineWave
A173	7	24	Harpsi.o	A422	26	16	Mandolin	A75	53	0	ChoirAah	B32	82	0	Saw Wave
A18	8	0	Clav.	A43	27	0	Jazz Gtr	A751	53	32	ChoirAh2	B321	82	1	Saw
A21	9	0	Celesta	A431	27	8	HawaiGt	A76	54	0	VoiceOoh	B322	82	8	DoctSolo
A22	10	0	Glocken	A44	28	0	CleanGtr	A77	55	0	SynVox	B33	83	0	SynCall
A23	11	0	MusicBox	A441	28	8	ChorusGt	A78	56	0	Orch Hit	B331	83	116	Accordn1
A231	11	116	StrngOct	A45	29	0	MutedGtr	A81	57	0	Trumpet	B34	84	0	ChifferL
A24	12	0	Vib	A451	29	8	FunkGtr	A82	58	0	Trombone	B35	85	0	Charang
A241	12	8	Vib.w	A452	29	16	FunkGtr2	A821	58	1	Trombne2	B351	85	116	Accordn2
A25	13	0	Marimba	A46	30	0	OvdrvGt1	A83	59	0	Tuba	B36	86	0	Solo Vox
A251	13	8	MarimbaW	A47	31	0	DstortG1	A84	60	0	MutedTp	B361	86	116	JVAccord
A26	14	0	Xylophon	A471	31	8	FeedbGtr	A85	61	0	Fr Horn	B37	87	0	5th SawW
A27	15	0	Tub-bell	A48	32	0	GtrHarmo	A851	61	1	FrHorn2	B371	87	116	KanounSt
A271	15	8	ChurcBel	A481	32	8	GtrFeedb	A86	62	0	Brass 1	B38	88	0	Bas&Lead
A272	15	9	Carillon	A51	33	0	AcouBass	A861	62	8	Brass 2	B41	89	0	Fantasia
A28	16	0	Santur	A52	34	0	FingBass	A87	63	0	SyBrass1	B42	90	0	Warm Pad
A31	17	0	Organ 1	A53	35	0	PickBass	A871	63	8	SyBrass3	B43	91	0	Polysynt
A311	17	8	DetunOr1	A54	36	0	Fretless	A872	63	16	AnBrass1	B44	92	0	SpVoice
A312	17	16	60'sOrg1	A55	37	0	Slap Bs1	A88	64	0	SyBrass2	B45	93	0	BowGlass
A313	17	32	Organ 4	A56	38	0	Slap Bs2	A881	64	8	SyBrass4	B46	94	0	MetalPad
A314	17	116	Or Orgn1	A57	39	0	SynthBs1	A882	64	16	AnBrass2	B47	95	0	Halo Pad
				A571	39	1	SyBas101					B471	95	116	Kanoun
				A572	39	8	SyBass 3								

GBN	PC	CC00	Sound Name	GBN	PC	CC00	Sound Name	GBN	PC	CC00	Sound Name
B48	96	0	SweepPad	B77	119	0	SynthDrm	B87	127	0	Applause
B51	97	0	Ice Rain	B771	119	8	808 Tom	B871	127	1	Laughing
B52	98	0	Soundtrk	B772	119	9	ElecPerc	B872	127	2	Screamin
B53	99	0	Crystal	B773	119	116	NayOct	B873	127	3	Punch
B531	99	1	SyMallet	B78	120	0	RevrS Cym	B874	127	4	Heart
B532	99	116	KnounOct	B81	121	0	GFrtNois	B875	127	5	Footstep
B54	100	0	Atmosph	B811	121	1	GtCNoise	B88	128	0	Gun Shot
B541	100	116	Kawala	B812	121	2	StrSlap	B881	128	1	MachGun
B55	101	0	Brightns	B82	122	0	Brtnoise	B882	128	2	Lasergun
B56	102	0	Goblin	B821	122	1	FIKClick	B883	128	3	Explosion
B561	102	116	KawlaOct	B822	122	116	Mizmar				
B57	103	0	EchoDrop	B83	123	0	Seashore				
B571	103	1	EchoBell	B831	123	1	Rain				
B572	103	2	Echo Pan	B832	123	2	Thunder				
B58	104	0	StarThem	B833	123	3	Wind				
B61	105	0	Sitar	B834	123	4	Stream				
B611	105	1	Sitar 2	B835	123	5	Bubble				
B62	106	0	Banjo	B835	123	116	MizmrOct				
B63	107	0	Shamisen	B84	124	0	Bird				
B64	108	0	Koto	B841	124	1	Dog				
B641	108	8	TKoto	B842	124	2	HorseGlp				
B65	109	0	Kalimba	B843	124	3	Bird 2				
B66	110	0	Bag Pipe	B85	125	0	Telephn1				
B67	111	0	Fiddle	B851	125	1	Telephn2				
B671	111	116	Rababa	B852	125	2	DCreakng				
B68	112	0	Shanai	B853	125	3	Door				
B71	113	0	TinkBell	B854	125	4	Scratch				
B711	113	116	Oud	B855	125	5	Windchim				
B72	114	0	Agogo	B86	126	0	Helicptr				
B721	114	116	OudTrem	B861	126	1	CarEngin				
B73	115	0	SteelDrm	B862	126	2	Car Stop				
B74	116	0	Woodblck	B863	126	3	Car Pass				
B741	116	8	Castanet	B864	126	4	CarCrash				
B741	116	116	Oud2TrVm	B865	126	5	Siren				
B75	117	0	Taiko	B866	126	6	Train				
B751	117	8	ConcrtBD	B867	126	7	Jetplane				
B752	117	116	OudOct	B868	126	8	Starship				
B76	118	0	MeloTom1	B869	126	9	BrstNois				
B761	118	8	MeloTom2	B8610	126	116	MizmarDu				
B762	118	116	Nay								



Music Style list

No.	Name	CC00	CC32	BPM	TimeS	No.	Name	CC00	CC32	BPM	TimeS	No.	Name	CC00	CC32	BPM	TimeS
11	Maks-Mlf	50	28	105	4/4	41	Katkofti	50	40	106	4/4	71	Bossa 1	22	23	150	4/4
12	Maksoum	50	27	120	4/4	42	Dabka	50	16	113	6/4	72	Bossa 2	22	24	168	4/4
13	Wehda-Kb	50	1	135	4/4	43	Leebi	50	42	100	4/4	73	Samba	27	14	117	4/4
14	Baladi	50	29	95	4/4	44	Fox	50	44	110	4/4	74	ChaCha	24	8	132	4/4
15	SaidiMdn	50	25	135	4/4	45	Greek	50	46	110	4/4	75	Mambo	38	8	95	4/4
16	SaidiMsh	50	71	96	4/4	46	Samai-T	50	37	120	10/4	76	Salsa	25	10	98	4/4
17	Saidi	50	19	110	4/4	47	Samai-D	50	36	105	3/4	77	Merengue	59	5	138	4/4
18	Fallahi	50	30	180	4/4	48	Zaffa	50	38	85	4/4	78	PopRock	39	17	138	4/4
21	Disco-Or	50	73	102	4/4	51	Rock	1	46	126	4/4	81	Rhumba	23	7	100	4/4
22	Gipsy-Or	50	72	91	4/4	52	Techno	2	95	137	4/4	82	Beguine	39	15	110	4/4
23	Malfouf1	50	31	100	4/4	53	Dance	2	96	108	4/4	83	Pdoble	40	3	122	4/4
24	Malfouf2	50	39	100	4/4	54	Hip Hop	3	23	97	4/4	84	Country	16	9	130	4/4
25	Masmoudi	50	34	120	8/4	55	8 Beat 1	6	60	60	4/4	85	Polka	19	10	124	4/4
26	Samba-Eg	50	43	100	4/4	56	8 Beat 2	6	57	88	4/4	86	Sl Waltz	18	9	90	3/4
27	Rhumba-E	50	8	190	4/4	57	16 Beat 1	7	65	94	4/4	87	Tango	26	8	120	4/4
28	Zar	50	5	99	4/4	58	16 Beat 2	7	66	58	4/4	88	Reggae	8	9	140	4/4
31	Rhumba-G	50	15	165	4/4	61	Ballad	4	21	116	4/4						
32	Khebeiti	50	48	180	4/4	62	Sl Rock 1	5	24	92	4/4						
33	Adani	50	50	180	4/4	63	Sl Rock 2	5	20	102	6/8						
34	Guartcha	50	53	120	4/4	64	Rock'N	10	28	185	4/4						
35	Conga	50	9	120	4/4	65	Boogie	9	10	156	4/4						
36	Sharh	50	14	159	3/4	66	Twist	10	32	162	4/4						
37	Maghrebi	50	21	159	6/4	67	Sl Swing	13	19	56	4/4						
38	Rai	50	10	99	4/4	68	MedSwing	13	13	134	4/4						

Drum Sets

	PC 1 STANDARD	PC 9 ROOM	PC 17 POWER	PC 25 ELECTRON	PC 26 TR-808	PC 33 JAZZ	PC 41 BRUSH	PC 49 ORCHESTRA	PC 57 SFX
27	High Q	<-	<-	<-	<-	<-	<-	Closed Hi-Hat [EXC1]	---
28	Slap	<-	<-	<-	<-	<-	<-	Pedal Hi-Hat [EXC1]	---
29	Scratch Push	<-	<-	<-	<-	<-	<-	Open Hi-Hat [EXC1]	---
30	Scratch Pull	<-	<-	<-	<-	<-	<-	Ride Cymbal	---
31	Sticks	<-	<-	<-	<-	<-	<-	<-	---
32	Square Click	<-	<-	<-	<-	<-	<-	<-	---
33	Metronome Click	<-	<-	<-	<-	<-	<-	<-	---
34	Metronome Bell	<-	<-	<-	<-	<-	<-	<-	---
35	Kick Drum 2	<-	<-	<-	<-	<-	<-	Concert BD 2	---
36	Kick Drum 1	<-	MONDO Kick	Elec BD	808 Bass Drum	<-	<-	Concert BD 1	---
37	Side Stick	<-	<-	<-	808 Rim Shot	<-	<-	<-	---
38	Snare Drum 1	<-	Gated SD 1	Elec SD	808 Snare Drum	<-	Brush Tap	Concert SD	High Q
39	Hand Clap	<-	<-	<-	<-	<-	Brush Slap	Catapults	Slap
40	Snare Drum 2	<-	<-	Gated SD	<-	<-	Brush Swirl	Concert SD	Slap
41	Low Tom 2*	Room Low Tom 2	Room Low Tom 2	Elec Low Tom 2	808 Low Tom 2	<-	<-	Timpani F	Scratch Push
42	Closed Hi-Hat [EXC1]	<-	<-	<-	808 Closed Hi-Hat [EXC1]	<-	<-	Timpani F#	Scratch Pull
43	Low Tom 1	Room Low Tom 1	Room Low Tom 1	Elec Low Tom 1	808 Low Tom 1	<-	<-	Timpani G	Sticks
44	Pedal Hi-Hat [EXC1]	<-	<-	<-	808 Closed Hi-Hat2 [EXC1]	<-	<-	Timpani G#	Square Click
45	Mid Tom 2	Room Mid Tom 2	Room Mid Tom 2	Elec Mid Tom 2	808 Mid Tom 2	<-	<-	Timpani A	Metronome Click
46	Open Hi-Hat [EXC1]	<-	<-	<-	808 Open Hi-Hat [EXC1]	<-	<-	Timpani A#	Metronome Bell
47	Mid Tom 1	Room Mid Tom 1	Room Mid Tom 1	Elec Mid Tom 1	808 Mid Tom 1	<-	<-	Timpani B	Guitar Sliding Finger
48	High Tom 2	Room High Tom 2	Room High Tom 2	Elec High Tom 2	808 High Tom 2	<-	<-	Timpani c	Guitar cutting noise (down)
49	Crash Cymbal 1	<-	<-	<-	808 Cymbal	<-	<-	Timpani d	Guitar cutting noise (up)
50	High Tom 1	Room High Tom 1	Room High Tom 1	Elec High Tom 1	808 High Tom 1	<-	<-	Timpani d#	String Slap of double bass
51	Ride Cymbal 1	<-	<-	<-	<-	<-	<-	Timpani e	Key Click
52	Chinese Cymbal	<-	<-	Reverse Cymbal	<-	<-	<-	Timpani e	Laughing
53	Ride Bell	<-	<-	<-	<-	<-	<-	Timpani f	Screaming
54	Tambourine	<-	<-	<-	<-	<-	<-	<-	Punch
55	Splash Cymbal	<-	<-	<-	<-	<-	<-	<-	Heart Beat
56	Cowbell	<-	<-	<-	808 Cowbell	<-	<-	<-	Footsteps 1
57	Crash Cymbal 2	<-	<-	<-	<-	<-	<-	Concert Cymbal 2	Footsteps 2
58	Vibra-slap	<-	<-	<-	<-	<-	<-	<-	Applause
59	Ride Cymbal 2	<-	<-	<-	<-	<-	<-	Concert Cymbal 1	Door Creaking
60	High Bongo	<-	<-	<-	<-	<-	<-	<-	Door
61	Low Bongo	<-	<-	<-	<-	<-	<-	<-	Scratch
62	Mute High Conga	<-	<-	<-	808 High Conga	<-	<-	<-	Wind Chimes
63	Open High Conga	<-	<-	<-	808 Mid Conga	<-	<-	<-	Car Engine
64	Low Conga	<-	<-	<-	808 Low Conga	<-	<-	<-	Car Stop
65	High Timbale	<-	<-	<-	<-	<-	<-	<-	Car Passing
66	Low Timbale	<-	<-	<-	<-	<-	<-	<-	Car Crash
67	High Agogo	<-	<-	<-	<-	<-	<-	<-	Siren
68	Low Agogo	<-	<-	<-	<-	<-	<-	<-	Train
69	Cabasa	<-	<-	<-	<-	<-	<-	<-	Jetplane
70	Maracas	<-	<-	<-	808 Maracas	<-	<-	<-	Helicopter
71	Short High Whistle [EXC2]	<-	<-	<-	<-	<-	<-	<-	Starship
72	Long Low Whistle [EXC2]	<-	<-	<-	<-	<-	<-	<-	Gun Shot
73	Short Guiro [EXC3]	<-	<-	<-	<-	<-	<-	<-	Machine Gun
74	Long Guiro [EXC3]	<-	<-	<-	<-	<-	<-	<-	Laser Gun
75	Claves	<-	<-	<-	808 Claves	<-	<-	<-	Explosion
76	High Wood Block	<-	<-	<-	<-	<-	<-	<-	Dog
77	Low Wood Block	<-	<-	<-	<-	<-	<-	<-	Horse-Gallop
78	Mute Cuica [EXC4]	<-	<-	<-	<-	<-	<-	<-	Birds
79	Open Cuica [EXC4]	<-	<-	<-	<-	<-	<-	<-	Rain
80	Mute Triangle [EXC5]	<-	<-	<-	<-	<-	<-	<-	Thunder
81	Open Triangle [EXC5]	<-	<-	<-	<-	<-	<-	<-	Wind
82	Shaker	<-	<-	<-	<-	<-	<-	<-	Seashore
83	Jingle Bell	<-	<-	<-	<-	<-	<-	<-	Stream
84	Bell Tree	<-	<-	<-	<-	<-	<-	<-	Bubble
85	Castanets	<-	<-	<-	<-	<-	<-	<-	---
86	Mute Surdo [EXC6]	<-	<-	<-	<-	<-	<-	<-	---
87	Open Surdo [EXC6]	<-	<-	<-	<-	<-	<-	<-	---
88	---	---	---	---	---	---	---	Applause	---

PC: Program change number (Drum Set Number)

<-: Same as the percussion sound of "STANDARD" (PC1)

---: No sound

[EXC]: Percussion sounds of the same EXC number cannot be played simultaneously.

PC 117
ORIENT

27	---
28	Zaghruta Loop
29	Zaghruta Loop
30	---
31	---
32	---
33	---
34	---
35	Kick Drum 2
36	Bass Drum (TR-707)
37	Rim Shot (TR-707)
38	Snare Drum (TR-707)
39	Hand Clap 2
40	Snare Drum (TR-707)
41	Low Tom 2
42	Closed Hi-Hat (TR-707)
43	Low Tom 1
44	Closed Hi-Hat (TR-707)
45	Mid Tom 2
46	Open Hi-Hat (TR-707)
47	Mid Tom 1
48	High Tom 2
49	Crash Cymbal (TR-707)
50	High Tom 1
51	Ride Cymbal 1
52	Doholla Dom
53	Doholla Sak
54	Tambourine
55	Doholla Tak 2
56	Cowbell
57	Doholla Tak 1
58	Cabasa
59	Doff Dom
60	Doff Tak 2
61	Low Bongo
62	Doff Tak 1
63	High Bongo
64	Doff Tak 3
65	Tabla Dom
66	Tabla Roll
67	Tabla Tak
68	Tabla Flam
69	Tabla Rim 1
70	Tabla Rim 3
71	Tabla Rim 2
72	Rek Dom 2
73	Rek Tak 2
74	Rek Dom 1
75	Rek Tek 1
76	Rek Rim
77	Rek Slap
78	---
79	Rek Khan-c
80	---
81	Rek Khan-o
82	Rek Loop
83	Rek Slap
84	Sagat L-o
85	Sagat R
86	Sagat L-c
87	Jingle Bell
88	---

C2

C3

C4

C5

C6

PC: Program change number (Drum Set Number)
 <-: Same as the percussion sound of "STANDARD" (PC1)
 ---: No sound
 [EXC]: Percussion sounds of the same EXC number cannot be played simultaneously.